

FIREFIGHT PRO 23



RGB MECHANICAL GAMING KEYBOARD

INSTRUCTION MANUAL

ADXMK0723



Contents

Safety Warnings.....	3	User Interface - Macro	12
Unpacking	4	User Interface - Light Effect	13
System Requirements	4	Hints and Tips.....	14
Function Keys.....	5	Specifications.....	14
Backlight Effect.....	6		
Customising the Backlight Effect	7		
Software Installation.....	8		
User Interface.....	9		
User Interface - Customise	10		
User Interface - Light	11		

Safety Warnings

- Read all the instructions carefully before using the unit and keep them for future reference.
- Retain the manual. If you pass the unit onto a third party, make sure to include this manual.
- Do not disassemble the keyboard or remove any parts.
- Do not immerse the keyboard in water or any liquid.
- Do not use the keyboard close to heat sources or expose to high temperatures.
- Do not use the keyboard where strong electromagnetic waves are present. Strong electromagnetic waves will cause damage to the keyboard.
- Keep the keyboard away from direct sunlight, moisture, dirt or abrasive chemical products (cleaning products etc).

Thank you for purchasing your new product.

We recommend that you spend some time reading this instruction manual in order that you fully understand all the operational features it offers. You will also find some hints and tips to help you resolve any issues.

Read all the safety instructions carefully before use and keep this instruction manual for future reference.

Unpacking

Remove all items from the packaging. Retain the packaging. If you dispose of it please do so according to local regulations.

The following items are included:

- Gaming keyboard
- Arm rest








System Requirements

Operating Systems: Microsoft® Windows® 8 / 10 / 11






Hardware: 1 available USB port

Function Keys

To access these functions, press the **FN** Key and the desired key together.

	Start the default Media Player programme.
	Decrease the Volume
	Increase the Volume
	Mute sound
	Stop playback
	Back to previous track
	Play/pause track







	Go to next track
	Start the default Web browser and load the Home Web page
	Start the default e-mail programme.
	Lock keyboard
	Open Calculator

* Not all functions are available, depending on your operating system.

Backlight Effect




To access these functions, press the **FN** Key and the desired key together.


	Adjust the backlight flashing sequence level.
	Switch the backlight on/off.
	Select different backlight effects. (18 modes / 1 customised mode)
	Adjust the backlight brightness.
Spacebar	Change the backlight colour.




Customising the Backlight Effect

You may customise the backlight for each keypress.

1. Press **Fn** +  repeatedly to select customise backlight mode.
2. Press and hold **Fn** +  to enter backlight setting mode. LED indicators will start flashing.
3. Press the keypress(s) repeatedly to choose the colour you wish (8 colours + 1 colourless).
4. Press and hold **Fn** +  when done.



To reset customised backlight effect to default setting, press and hold **Fn** +  ⏻ until all backlights start lighting in succession.

Software Installation

1. Plug the unit into the USB port of your computer.
2. Download the latest gaming software from **<https://downloads.adxgaming.com>** (under **ADX HUB LIGHTING SOFTWARE DOWNLOAD**)
3. Run the software (**ADX HUB Setup.exe**) installer.
4. Follow the installation instruction to complete the installation.
5. Choose **ADX HUB.exe** from the desktop to start the software.



The software is not available for MAC OS.


User Interface

1. Choose **ADX HUB.exe** from the desktop to launch the software.
2. Select "**Keyboard**" and then "**ADXMK0723**" at the bottom of the connected device list to enter the interface.




User Interface - Customise

1. Select **Customise**, and then select your customised settings.
2. After settings, save your own preference in the **Profile** menu.
3. Select **"Apply"** to implement your settings, or **"Reset"** to reset all settings.




User Interface - Light

1. Select **Light** to enter the **Lighting Settings** menu.
2. Choose your preference among the below:
 - **Mode**
 - **Brightness**
 - **Speed**
 - **Color Mode**
3. Select "**Apply**" to implement your settings, or "**Reset**" to reset all settings.



User Interface - Macro

1. Select **Macro**, and then “+” to create a **New Macro Command**.
2. Press **Start Recording**.
3. After recording your input command, press **Stop Recording**.
4. You may edit your recorded commands on the right menu.
5. Select “**Apply**” to implement your settings, or “**Reset**” to reset all settings.



User Interface - Light Effect

If one more ADX gaming device is connected, you may synchronize their light effects.

1. Select **Light Effect**, and the devices you want to apply the light effect.
2. Select your preferred **Lighting Settings (Mode, Brightness and Speed)**.
3. Select "**Apply**" to implement your settings.



To reset the setting of a particular device, select a connected device shown in the menu, and then select **Reset**.



Hints and Tips

- Make sure the USB plug is fully plugged into a USB port and the computer is on or try to use a different USB port.
- If the unit is not working properly, re-insert the USB plug into the USB port.

Specifications

Model	ADXMK0723
Dimensions (L × W × H)	436.9 × 125.7 × 31.9 mm
Net Weight	1029.5 g

Features and specifications are subject to change without prior notice.



The symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste

electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

All trademarks are the property of their respective owners and all rights are acknowledged.

Currys Group Limited (co. no. 504877)
1 Portal Way, London, W3 6RS, UK

EU Representative

Currys Ireland Limited (259460)
3rd Floor Office Suite
Omni Park SC, Santry, Dublin 9, Republic of Ireland

IB-ADXMK0723-220815V1